



3DBUOY™

PATENTS ISSUED AND PENDING



TO INFLATE THE 3DBUOY™

- 1** Locate the water ballast plug found on the bottom portion of the 3DBUOY™. While pulling up on the center D-ring, fill the water ballast section with fresh or salt water. When full, secure plug tightly.
- 2** Locate the main inflation plug found on the main body of the 3DBUOY™. Inflate the main air chamber of the 3DBUOY™ until fully inflated. **DO NOT OVER-INFLATE!!** This bladder does not feature a pressure release protection and **WILL** burst if overinflated.
- 3** Locate the 3 inflation plugs on the 3DBUOY™ triangle. Inflate all 3 sides and secure plugs in place.
- 4** Slide the 3DBUOY™ Triangle over the smaller 3DBUOY™ triangle. This should be a snug fit. The 3 holes on the corners of the 3DBUOY™ triangle allow you to secure the 3DBUOY™ triangle to the 3DBUOY™ base. Tie all 3 corners of the triangle to the base of the 3DBUOY™.

IMPORTANT INFO YOU SHOULD KNOW

Before using this flag in your area, please check your state's regulations for Dive markers to ensure 3DBUOY™ laws in regards to the size of the dive markers, however, each state has their own set of regulations.

It is owner's responsibility to ensure compliance with all local laws.

STORAGE: It is recommended that you empty the water ballast and rinse the 3DBUOY™ with fresh water and allow the 3DBUOY™ to dry completely before storing.



California Prop 65 WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.